

BX92R Chipper Parts Manual Prior to S/N 192R30



Foreword

EMB Mfg. has prepared this parts manual to assist customers in ordering quality OEM replacement parts.

Proper and regular service and replacing old, worn or broken parts with the correct OEM parts are essential to prolonging the life of your EMB product. Please refer to this manual before ordering any replacement parts.

All information contained in this parts manual is based on the latest product specification available at the time of printing this manual. If your product differs from the specifications contained within this manual contact EMB Mfg. for information.

EMB reserves the right to alter specifications on their products at any time.

Reproduction of this parts manual of any kind is prohibited without prior written permission from EMB Mfg.


Table of Contents


Main Parts Breakdown	5
Discharge Chute Parts Breakdown	7
Roller Feed Chute Parts Breakdown	8
Z56203 Valve Breakdown	11
Binacchi PTO Parts Breakdown	12
Decal Breakdown	14




BX92R Main Parts Breakdown

22








13

22






920R PARTS BREAKDOWN


ITEM	PART NO.	Description	QTY.
1	1013M025	Arm Capture Bushing	1
2	1020L051	Strap, Hopper Flap	1
3	1020L064	Cover, Top Roller	1
4	1020L068	Valve Lever	1
5	10208003	Flap, Hopper	2
6	1020W001	Hopper, Roller Feed	1
7	1020W002	Arm, Upper Roller	1
8	1020W003	Roller, Upper Feed	1
9	1020W004	Roller, Lower Feed	1
10	1020W007	Valve Link	1
11	1020W405	Handle, Feed Regulating	1
12	Z11302	Clevis Pin 3/16 x 3/4	1
13	Z11313	Clevis Pin 1/4 x 3/4	3
14	Z12301	Cotter Pin 3/32 X 3/4	4
15	Z24101	P208 Pillow Block 1-1/2	2 2
16	Z25204	4-Bolt Bearing 1-1/2" Bore	
17	Z29201	Grease Fitting, 1/8NPT	1
18	Z29202	Grease Zerk 1/4NF	2
19	Z31502	Spring, 1-3/4 x 9 Heavy	4
20	Z51122	Nipple, MP x MP 0808	1
21	Z51161	Tee, FP x FP x MP 080808	1
22	Z51331	Elbow 90 MP x FPX 0808	5
23	Z51384	#10ORB x 1/2FNPT 90 Elbow	4
24	Z52310	1/2 Hose MP08 x MP08 x 48"	2
25	Z52314	1/2 Hose, MP08 x MP08 x 10"	1
26	Z52317	1/2 Hose,1/2MP x 1/2MP x 20"	1
27	Z52318	1/2 Hose, 1/2MP x 1/2MP x 130"	2 2
28	Z54104	300 Series Hydraulic Motor	
29	Z56203	Control Valve, Single Spool	1
30	Z56303	Hydraulic Flow Control	1
31	Z71105	Hex Bolt 1/4NC x 1/2	4
32	Z71107	Hex Bolt 1/4NC x 3/4	4
33	Z71122	Hex Bolt 1/4NC x 2-1/4	2
34	Z71217	Hex Bolt 5/16NC x 1-3/4	3
35	Z71515	Hex Bolt 1/2NC x 1-1/2	4
36	Z71527	Hex Bolt 1/2NC x 2-3/4	4
37	Z71617	Hex Bolt 5/8NC x 1-3/4	4
38	Z72111 Z72221	Hex Lock Nut 1/4NC	2 3
39	Z/2221	Hex Lock Nut 5/16NC	3
40	Z72231	Hex Lock Nut 3/8NC	4
41	Z72251	Hex Lock Nut 1/2NC	8
42	772261	Hex Lock Nut 5/8NC	4
43	Z72911	Acorn Nut, 3/8NC	2
44	Z74110	Set Screw 1/4NC	2
45	Z74121	Set Screw 5/16NC	4
46	Z76531	Eye Bolt 3/8NC x 3-1/2	3
47	Z76712	Self-tapping Screw #10	3
48	Z96503	Manual Tube 3-1/2 Short	

Page 8 Oct 2010






Z56203 Valve Breakdown



CASE NOTE: FORE REMOVING VALVE SPOOL OR SPOOL SLEEVE REMOVE DETENT LS-3000 KITS AND CARTRIDGE			ITS AND CARTRIDGES	
ADJUSTING CART., DETENT PISTON AND STEEL BALL. INSTALL SPOOL AND SPOOL SLEEVE BEFORE REINSTALLING STEEL BALL.	ITEM	QTY	PART NO.	DESCRIPTION
PRESSURE RELEASE DETENT This feature provides a pressure release detent for the spool 'aut' (handle in) position. When the spool is manually placed in the detent position oil is directed to the 'B' work part (the part away from the handle). When the pressure in the 'B' port reaches a preset level the detent will release and the spool will center. The factory setting is 1400 psi. The detent release pressure is adjustable by loosening the jam nut and turning the adjusting screw. Turning the adjusting screw clockwise will increase the detent release pressure and counterclockwise will decrease the detent release pressure. NOTE: if the detent release pressure is set too high the spool will not center, if the pressure is too low the detent will not hold. If cap screw item 6 becomes loose detent will not function properly.	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15		670700019 670500033 670500026 671400010 670500026 220000953 670500032 230001125 230009009 240019013 240000014 240019014 240019014 240019014	DETENT SLEEVE WASHER SPRING STOP CUP WASHER CAP SCREW SPACER SNAP RING STEEL BALL BACK-UP WASHER O-RING O-RING O-RING BACK-UP WASHER PISTON BACK-UP WASHER
RELIEF VALVE An adjustable ball spring relief valve is standard on all LS-3000 valves. The standard factory setting is 2250 psi @ 3 gpm and 120°F. Other settings can be specified. The relief pressure is adjusted by removing acorn nut, and turning the adjusting screw clockwise will increase the pressure and counterclockwise will decrease the pressure (a pressure gauge must be installed in the inlet line whenever the relief pressure is adjusted). Do not backout adjusting screw to the point it falls out. WARNING: OVERPRESSURE MAY CAUSE SUDDEN AND UNEXPECTED FAILURE OF A COMPONENT IN THE HYDRAULIC SYSTEM RESULTING IN SERIOUS PERSONAL INJURY. ALWAYS USE A GAUGE WHEN ADJUSTING A RELIEF VALVE.	16 17 18 19 20 21 22 23	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	240016067 240016068 240019008 660330002 660125004 240016086 240000210 671100012 660530001 660125004 660330002 660130007 660130001	O-RING O-RING BACK-UP WASHER DETENT ADJUSTING CART. RELIEF KIT U-CUP O-RING PISTON SLEEVE LS-3000 SEAL KIT RELIEF KIT DETENT ADJUSTING CART. PRESSURE RELEASE DETENT KIT COMPLETE HANDLE KIT



Page 12 Oct 2010


Binacchi PTO Parts List

POS.	DESCRIPTION	Q	PART#
01	YOKE	1	0800803A60
02	CROSS JOURNAL ASS.	2	08208
05	OUTER TUBE YOKE	1	08080021
08	FLEXIBLE PIN	1	098701075
12	CM. 100 CARDAN TUBE(*)	1	09881544100
13	CM. 100 CARDAN TUBE(*)	1	09881455100
16	FLEXIBLE PIN	1	098701065
17	INNER TUBE YOKE	1	08080011
21	SHEAR BOLT	1	08808P70
25	CONE SHIELD BELL 07-08	2	021908C001
26	OUTER BEARING	1	025508C001
27	OUTER BASE CONE 07-08	1	025408C001
28	SCREW	8	0998052242
29	OUTER SAFETY TUBE	1	0988981NB8066
30	INNER SAFETY TUBE	1	0988975NB8066
31	INNER BASE CONE 07-08	1	025408C002
32	INNER BEARING	1	025508C002
40	CHAIN	1	0252000001
48	LABEL DANGER OUTER DRIVE TUBE	1	09872006
49	EXTERNAL SHIELD LABEL	1	09872003
51	COMPLETE PUSH BUTTTON	1	0986014060
71	YOKE FOR LB8	1	088608553
72	GREASE NIPPLE	1	0984010150
73	STEEL BALL	24	098680516
74	HUB	1	08868P70
75	CONIC SCREW	1	0408000061
76	NUT AND BOLT M12X65 10.9	1	Z19408
93	OUTER HALF SHAFT	1	B8061US2
94	INNER HALF SHAFT	1	B8061US1098001
97	SAFETY GUARD	1	083US08061

Note: Always check brand of PTO shaft when ordering PTO parts. For other brands then the Binacchi shafts shown, please call the factory @ 877-695-9283

BX92R DECAL BREAKDOWN

ITEM	PART NO.	DESCRIPTION	QTY
1	Z94056	WALLENSTEIN Decal	2
2	Z94019	1" Dia. Made In Canada	5
3	Z94072	BX92R	2
4	Z94007	DANGER - Rotating Blades	3
5	Z94006	CAUTION - Read Manual	1
6	Z94009	DANGER - Rotating Driveline Hazard	1
7	Z94008	DANGER - Thrown Object Hazard	3
8	Z94015	Reverse, Neutral, Feed - RH	1
9	Z94014	Reverse, Neutral, Feed - LH	1
10	Z94005	High Pressure	2



Page 14 Oct 2010

Decals BX92R

Z94056





Z94007



Z94019



794006

A CAUTION

- Read and understand operator's manual before starting. Review safety instructions annually.
- Turn machine off, stop and disable engine, remove ignition key and place in your pocket, set park brake and wait for all moving parts to stop before adjusting, servicing, maintaining, repairing or unplugging.




- Keep the working area clean and free of debris to prevent slipping or tripping. Operate only on level ground.
- Close and secure rotor cover before operating.
- Close and secure all guards, deflectors and shields before starting
- Keep hydraulic lines and fittings tight, in good condition and free
- Keep hands, feet, hair and clothing away from moving parts. Never wear loose clothing around machinery
- Keep driveline universal joint angles equal and small as possible.
- Do not point discharge at people, animals or buildings. Rotor can expel wood chips fast enough to cause injury.
- Do not allow children, animals or unauthorized people into working area.
- Do not run machine inside a closed building to prevent asphyxiation from engine exhaust.
- Use care when feeding material into chipper. Do not send metal, bottles, cans, rocks, glass or other foreign material into wood chipper. If foreign material enters chipper, stop the machine, turn engine off and place ignition key in your pocket and wait for all moving parts to stop before removing material and/or unplugging. Inspect machine for damaged or loose parts before returning
- Always wear P.R.E. (Personal Protective Equipment) such as safety goggles and heavy gloves whenever operating machine.
- Do not place hands or any body parts into feed hopper during operation.
- Do not move or transport chipper when the rotor is turning.
- Do not exceed a safe travel speed when transporting. Cross safety chain under hitch on trailer model when attaching to a truck.


Z94009



Z94015



Z94014



Z94008



Z94005



To prevent serious injury or death from high-pressure fluid:

- Relieve pressure on system before repairing or adjusting.
- Wear proper hand and eye protection when searching for leaks. Use wood or cardboard instead of hands.

Keep all components in good repair.



WALLENSTEIN Products Manufactured by:

EMB MFG Inc.

4144 Boomer Line St. Clements, Ontario Canada NOB 2M0 Phone: 1-877-695-9283

Fax: 519-699-4146 www.embmfg.com