

Foreword

EMB Mfg. has prepared this parts manual to assist customers in ordering quality OEM replacement parts.

Proper and regular service and replacing old, worn or broken parts with the correct OEM parts are essential to prolonging the life of your EMB product. Please refer to this manual before ordering any replacement parts.

All information contained in this parts manual is based on the latest product specification available at the time of printing this manual. If your product differs from the specifications contained within this manual contact EMB Mfg. for information.

EMB reserves the right to alter specifications on their products at any time.

Reproduction of this parts manual of any kind is prohibited without prior written permission from EMB Mfg.

Table of Contents

Bolt Torque	4
Hydrualic Fitting Torque	5
Cylinder	6
Main Parts	7
Valve Assembly	9
Decal Breakdown	10

2035T100 WX460 RevBC2 Parts Manual.110511

Bolt Torque

CHECKING BOLT TORQUE

Thetablesshownbelowgivecorrecttorque values for various bolts and capscrews. Tighten all bolts to the torques specified in chart unless otherwise noted. Check tightness of bolts periodically, using bolt torque chart as a guide. Replace hardware with the same strength bolt.

ENGLISH TORQUE SPECIFICATIONS						
Bolt	Bolt Torque*					
Diamter "A"				E 5 (lb-ft)	SAE 8 (N.m)(Ib-ft)	
1/4"	8	6	12	9	17	12
5/16"	13	10	25	19	36	27
3/8"	27	20	45	33	63	45
7/16"	41	30	72	53	100	75
1/2"	61	45	110	80	155	115
9/16"	95	60	155	115	220	165
5/8"	128	95	215	160	305	220
3/4"	225	165	390	290	540	400
7/8"	230	170	570	420	880	650
1"	345	225	850	630	1320	970
		SA	E-2	SAE-5	SAE-8	
			~	~	•	

Torque figures indicated above are valid for non-greased or non-oiled threads and heads unless otherwise specified. Therefore, do not grease or oil bolts or capscrews unless otherwise specified in this manual. When using locking elements, increase torque values by 5%.

* Torque value for bolts and capscrews are identified by their head markings.

METRIC TORQUE SPECIFICATIONS					
Bolt	Bolt Bolt Torque*				
Diameter	8	.8	10.9		
"A"	(N.m) (lb-ft)		(N.m)	(lb-ft)	
M3	0.5	0.4	1.8	1.3	
M4	3	2.2	4.5	3.3	
M5	6	4	9	7	
M6	10	7	15	11	
M8	25	18	35	26	
M10	50	37	70	52	
M12	90	66	125	92	
M14	140	103	200	148	
M16	225	166	310	229	
M20	435	321	610	450	
M24	750	553	1050	774	
M30	1495	1103	2100	1550	
M36	2600	1917	3675	2710	


Hydraulic Fitting Torque

Tightening Flare Type Tube Fittings *

- 1. Check flare and flare seat for defects that might cause leakage.
- 2. Align tube with fitting before tightening.
- 3. Lubricate connection and hand tighten swivel nut until snug.
- 4. To prevent twisting the tube(s), use two wrenches. Place one wrench on the connector body and with the second tighten the swivel nut to the torque shown.


Tube Size OD	Nut Size Across Flats	Torque Value∙		Recom Turns To (After Tighte	Tighten Finger
(in.)	(in.)	(N.m)	(lb-ft)	(Flats)	(Turn)
3/16	7/16	8	6	1	1/6
1/4	9/16	12	9	1	1/6
5/16	5/8	16	12	1	1/6
3/8	11/16	24	18	1	1/6
1/2	7/8	46	34	1	1/6
5/8	1	62	46	1	1/6
3/4	1-1/4	102	75	3/4	1/8
7/8	1-3/8	122	90	3/4	1/8

The torque values shown are based on lubricated connections as in reassembly.





5" x 24" STROKE CYLINDER PARTS

Γ	ITEM	PART NO.	Description	QTY.
	1	G500-2508A	5" Bore x 2-1/2" Rod Gland With Seals	1
Γ	2	P100-500SA	5" Bore Piston With Seals	1
	3	2015C5014	Barrel, 5"	1
	4	2015C5012	Rod,2-1/2x 1	1
	5	Z72292G8	Hex Lock Nut 1NF Grade 8	1
	6	SLK-5025	Seal Kit, 5 x 2-1/2	1



This Page is Intentionally Blank





TWO PANEL WX460 DECAL BREAKDOWN

ITEM	PART NO.	DESCRIPTION	QTY
1	Z94119	CAUTION - Read Manual	1
2	Z94123	Keep Feet Back	2
3	Z94067	Clear Guide	2
4	Z94056	Wallenstein	2
5	Z94019	Made in Canada	3
6	Z94124	Keep Hands Back	1

