



# Uncratering and Assembly Instructions Enclosed



# **WALLENSTEIN**

## **Optional Fines Pan for MX80/50P & MX80/50G MANURE SPREADERS**

### **WARNING**

Detailed information on standard workshop and safety procedures, and general servicing operations is not included in this manual, which has been prepared to assist qualified service personnel. EMB MFG. assumes no responsibility or liability for **PERSONAL INJURY** or **EQUIPMENT DAMAGE** which results from any servicing procedure performed, including those instructions outlined in this manual. Before performing a servicing operation, an individual must have determined to his/her satisfaction that a personal injury or **EQUIPMENT** damage will not result from the servicing procedure or tools selected.


### **IMPORTANT**

Please refer to torque chart for all torque specifications.

## Installing the Fines Pan

1. Locate the packing box containing the Fines Pan (with latches & hardware pkg.)


*Photo 1*



2. At the rear of spreader, attach both Latch Brackets to left and right side near the bottom of equipment. Use (4) Carriage Bolt, 5/16NC x 5/8 and (4) Hex Lock Nut 5/16NC supplied in the hardware pkg. *Photo 2*



3. Attach the Fines Pan at the brackets on rear of spreader and secure with (2) **Hex Bolt 1/2NC** & (2) **Hex Locknut 1/2NC**. *Photo 3*



4. Swing Fines Pan down to brackets and secure with Lynch Pin. *Photo 4*

