


PARTS MANUAL

Serial Number 420R001 & up

LXG420R SKID STEER LOG GRAPPLE



Foreword

This Wallenstein parts manual is prepared to assist customers in ordering quality OEM replacement parts.

Regular maintenance combined with replacing old, worn or broken parts with the correct OEM parts is essential in prolonging the life of your Wallenstein product. Refer to this manual to identify replacement parts.

To order parts, contact your Wallenstein dealer or distributor. Have the product model and serial number handy.

If your dealer is no longer available, please go to our website: <http://wallensteinequipment.com> and click on the [Dealer Locator](#) to find the nearest dealer.

All information contained in this parts manual is current as per the revision date at the bottom of the page. Wallenstein reserves the right to change product specifications at any time without notice.

If your product specifications differ from those contained in this manual, contact Wallenstein for current information.

Reproduction of information in this parts manual is prohibited without prior written permission from Wallenstein Equipment Inc.

Wallenstein Equipment Inc. • © 2019



WARNING!

Refer to the operators manual for safe operation and maintenance.

Maintenance should be performed by trained personnel only.


Serial Number Location

Always provide the model and serial number of your Wallenstein product when ordering parts or requesting service or other information. This information is found on the product information plate as shown below.

Record your product information here for future reference.

Model _____

Serial Number _____



www.wallensteinequipment.com

Contents

Main Parts.....4

Grapple Assembly.....5

Outer Fork Assembly Detail6

Cylinder Detail7

Valve Assembly Detail7

Hydraulic Function Selector Switch.....8

Hydraulic Circuit9


Decal Layout.....10

Accessories.....11

Common Bolt Torque Values12

Hydraulic Fitting Torque Values13


Main Parts



Item No.	Part No.	Description	Qty
1	6073W001	Mainframe	1
2	6071W102	Hose Mount Whip	1
3	6018W007	Hanger	1
4	3011L176	Clamp, Two Hose	4
5	6018L031	Cover, Hydraulic Hose	1
6	6018M015	Pin, Rotator Mount	1
7	6073L014	Plate, Hydraulic Valve Cover	1
8	Z27109	Composite Bearing, 1" ID x 1-1/2"L x 1/8" Wall	2
9	Z54107	Hydraulic Rotator, CR300W	1
10	Z71120	Hex Bolt, 1/4NC x 2"	1
11	Z71217	Hex Bolt, 5/16NC x 1-3/4"	2
12	Z71225	Hex Bolt, 5/16NC x 2-1/2"	1
13	Z71911	Hex Bolt, 1NC x 4-1/2"	2


Item No.	Part No.	Description	Qty
14	Z72211	Hex Lock Nut, 1/4NC	1
15	Z72221	Hex Lock Nut, 5/16NC	2
16	Z72291	Hex Lock Nut, 1NC	2
17	Z72955	Rivet Nut, 1/4NC x 165	2
18	Z72956	Rivet Nut, 5/16NC x 150	2
19	Z72957	Rivet Nut, 5/16NC x 312	7
20	Z76111	Flange Bolt, 1/4NC x 3/4"	2
21	Z76121	Flange Bolt, 5/16NC x 3/4"	4
22	Z76125	Flange Bolt, 5/16NC x 1"	1
23	Z76127	Flange Bolt, 5/16NC x 1-3/4"	2
24	Z79464	Double Hose Clamp, 13/16" OD	1
25	Z96505	Manual Tube, 2" Short	1

Grapple Assembly




Item No.	Part No.	Description	Qty
1	6018W001	Grapple Housing	1
2	6018W002	Inner Fork	1
3	6018W010	Short Cylinder Pin	1
4	6018W008	Inner Fork Pin	2
5	6018W009	Outer Fork Pin	2
6	Z27109	Composite Bearing, 1" ID x 1-1/2" long x 1/8" Wall	4
7	Z72531	Serrated Flange Locknut, 3/8NC	5
8	Z76134	Flange Bolt, 3/8NC x 1"	1
9	Z76139	Flange Bolt, 3/8NC x 7/8"	4

Outer Fork Assembly Detail





Item No.	Part No.	Description	Qty
1	6018C001	Cylinder, 2" x 1-1/4" x 8-5/8"	1
2	6018L026	Washer, Linkage Retaining	2
3	6018W003	Outer Fork	1
4	6018W004	Linkage	1
5	6018W004H	Linkage Mirror	1
6	6018W011	Long Cylinder Pin	1
7	Z27110	Composite Bearing, 1" ID x 1" long x 1/8" Wall	8
8	Z46204	External Retaining Ring, 1"	2
9	Z72531	Serrated Flange Locknut, 3/8NC	1
10	Z76134	Flange Bolt, 3/8NC x 1"	1

Cylinder Detail




Item No.	Part No.	Description	Qty
1	6018C0013	Rod, 1-1/4" x 3/4NF	1
2	6018C0014	Barrel, 2"	1
3	G200-125S	Gland, 2" x 1-1/4"	1
4	P750-200SP	Piston, 2" Bore	1
5	Z72276G8	Hex Top-lock Nut, 3/4NF G8	1

Valve Assembly Detail



Item No.	Part No.	Description	Qty
1	Z51562	Elbow 90, MJIC x FJICX 0808	3
2	Z51647	Straight, MJIC x MORB 0810	3
3	Z51558	Elbow 90, MJIC x MORB 0810	3
4	Z56615	Single Spool Valve, OC Selector SOL x 21GPM	1
5	Z75122	SHCS, 5/16NC x 3"	2

Hydraulic Function Selector Switch



Item No.	Part No.	Description	Qty
1	Z72202	Hex Lock Nut, #8NC	4
2	Z78309	Machine Screw, #8NC x 1/2"	4
3	6072A205	Selector Switch Assembly	1

Hydraulic Rotator

Hydraulic Cylinder

Control Valve


Item No.	Part No.	Description	Qty
1	6018F001	3/8" Hose, FJIC06 x 90FJIC06 x 21"	2
2	6073F002	3/8" Hose. 45FJIC08 x FJIC08 x 84"	4

Item No.	Part No.	Description	Qty
1	6018F001	3/8" Hose, FJIC06 x 90FJIC06 x 21"	2
2	6073F002	3/8" Hose, 45FJIC08 x FJIC08 x 84"	4
3	6073F001	1/2" Hose, FJIC08 x MP08 x 80"	2
4	Z51937	Straight, MJIC x MBSPP 0806 x 0.047" Orifice	1
5	Z51919	Flat-Face Coupler, FP08 x M ISO 16028	1
6	Z51920	Flat-Face Coupler, FP08 x F ISO 16028	1

Decal Layout



IMPORTANT! If parts are replaced that have safety signs on them, new signs must be applied. Safety signs must always be replaced if they become damaged, are removed, or become illegible.

Safety signs are included in the product decal kit available from your authorized dealer. Decals are not available separately.



Accessories

Call your dealer for pricing and availability

	48" Log Peavey – P/N Z99001 Quality 2-3/8" diameter hardwood handle, with a Western Duck Bill Hook. Helps to move those heavy log timbers into position.
	Skidding Tongs – P/N Z99003 Heavy Duty Forged Ring Skidding Tongs Maximum Opening: 25" Minimum Opening: 4-1/2" Tough log skidding tongs are a quick and easy way to skid logs.

Common Bolt Torque Values

Checking Bolt Torque

The tables shown give correct torque values for various bolts and capscrews. Tighten all bolts to the torque values specified in the table, unless indicated otherwise. Check tightness of bolts periodically.

IMPORTANT! If replacing hardware, use fasteners of the same grade.

IMPORTANT! Torque figures indicated in the table are for non-greased or non-oiled threads. Do not grease or oil threads unless indicated otherwise. When using a thread locker, increase torque values by 5%.



NOTE: Bolt grades are identified by their head markings.

Imperial Bolt Torque Specifications

Bolt Diameter	Torque Value					
	SAE Gr. 2		SAE Gr. 5		SAE Gr. 8	
	lbf•ft	N•m	lbf•ft	N•m	lbf•ft	N•m
1/4"	6	8	9	12	12	17
5/16"	10	13	19	25	27	36
3/8"	20	27	33	45	45	63
7/16"	30	41	53	72	75	100
1/2"	45	61	80	110	115	155
9/16"	60	95	115	155	165	220
5/8"	95	128	160	215	220	305
3/4"	165	225	290	390	400	540
7/8"	170	230	420	570	650	880
1"	225	345	630	850	970	1320



SAE Gr. 2



SAE Gr. 5



SAE Gr. 8

Metric Bolt Torque Specifications

Bolt Diameter	Torque Value			
	Gr. 8.8		Gr. 10.9	
	lbf•ft	N•m	lbf•ft	N•m
M3	0.4	0.5	1.3	1.8
M4	2.2	3	3.3	4.5
M6	7	10	11	15
M8	18	25	26	35
M10	37	50	52	70
M12	66	90	92	125
M16	166	225	229	310
M20	321	435	450	610
M30	1,103	1 495	1,550	2 100
M36	1,917	2 600	2,700	3 675



8.8



10.9

Hydraulic Fitting Torque Values

Tightening Flare Type Tube Fittings

1. Check flare and flare seat for defects that might cause leakage.
2. Align tube with fitting before tightening.
3. Hand-tighten swivel nut until snug.
4. To prevent twisting the tube, use two wrenches. Place one wrench on the connector body and tighten the swivel nut with the second. Torque to values shown.

If a torque wrench is not available, use the FFFT (Flats From Finger Tight) method.

Hydraulic Fitting Torque					
Tube Size OD	Hex Size Across Flats	Torque value		Flats From Finger Tight	
Inches	Inches	lbf•ft	N•m	Flats	Turns
3/16	7/16	6	8	2	1/6
1/4	9/16	11–12	15–17	2	1/6
5/16	5/8	14–16	19–22	2	1/6
3/8	11/16	20–22	27–30	1-1/4	1/6
1/2	7/8	44–48	59–65	1	1/6
5/8	1	50–58	68–79	1	1/6
3/4	1-1/4	79–88	107–119	1	1/8
1	1-5/8	117–125	158–170	1	1/8

Values shown are for non-lubricated connections.